



DECORATIVE COVERS INSTALLATION INSTRUCTIONS

General

SpacePak's Decorative Covers are installed over our standard white plastic terminator plates supplied in the installation kits. The 5" standard terminator plate is to be installed as per installation manual instructions supplied with the fan coil unit. The covers measure 6-5/8" in diameter X 5/8" thick and have (2) pre-drilled holes.

Installation Note

It is important to note that the decorative covers are wider than the standard 5" terminator plates. Verify the decorative cover position will not interfere with walls and architectural elements before installing the standard terminators.

Field Required Parts: not factory supplied

Installing the decorative covers properly will require the following field supplied parts:

1. Silicone caulk
2. 1/8" X 7/16" wood screw (two per cover)

Installation

Decorative covers should be installed using the following steps:

1. Install the standard white room terminator plates per installation manual instructions supplied with the fan coil unit.
2. Place cover over terminator plate so that cover holes are at 90° of terminator holes.
3. With a nail, etch hole location on white terminator plate through both holes.
4. Using 1/16" drill bit, pilot holes for screws through white terminator plate in both locations.
5. Apply silicone caulk to interior portion of cover.
6. Position cover in place so that both pre-drilled holes line-up with drilled holes in terminator plate.
7. Screw the cover into place.



260 North Elm Street
Westfield, MA 01085
www.spacepak.com